

扫描仪安装指南

机台规格以实际出货为主不另行通知。
如随机未附保证书，将以安装说明书的解释或提示为主。

简体中文

English

1 安装驱动程序

- 在进行硬件安装前，请先完成驱动程序的安装。进行此步骤时，请勿将计算机与USB连接线连接。
- 1. 将驱动程序安装光盘放入光驱中。
- 2. 按照屏幕上的指示完成安装。
- 如果放入驱动程序安装光盘后，软件并未自动进行安装，请您依照以下步骤完成安装。
- 1. 选择开始菜单中的[运行] (1-1)。
- 2. 在[运行]对话框中输入[光盘代号：\run]后，按[确定] (1-2)。
- 3. 按照屏幕上的指示完成安装。

注意：
安装结束后，系统会询问你是否重新启动，请选择[确定] (1-3)。

1 Installing Drivers

- Please complete the driver installation before installing the scanner.
- 1. Insert the driver Installation CD into your disk drive.
- 2. Follow all on screen instructions.
- If after inserting the driver Installation CD into your disk drive, the driver Installation Welcome screen does not appear, do the following.
- 1. Click on "Start" and select "Run" (1-1).
- 2. In the "Run" dialog box, type "drive :\run" where drive is your CD-ROM drive and click "OK" (1-2).
- 3. When you are presented with the option of whether to restart Windows after completing the driver installation, please choose "OK" (1-3).

2 硬件安装

- 计算机开机后，请将USB电缆的一端插入计算机的USB接口中，将电源线连接到扫描仪并将另一端插入电源插座中 (2-1)。
- 将电源接上后，Windows®操作系统会自动侦测扫描仪并更新系统设置 (2-2)。

2 Installing Hardware

- With the power to your PC on, connect the scanner's USB cable to the USB port of your PC (2-1).
- Connect the power adapter to the scanner and plug it into an appropriate power outlet (2-2).

Microsoft Windows® 2000 用户注意事项

- 当您完成软件安装并且重新开机后，Windows® 2000将会自动侦测您所安装的新硬件，同时会询问是否要继续安装，请按下[确定]键即可继续完成安装步骤。
- Microsoft数字签名的目的在于保证软件在视窗环境下操作正常。而本产品所提供的最新驱动程序目前正由微软公司测试认证中，使用者无须担心。
- 本公司的全球资讯网站上将持续更新产品信息，欢迎您随时莅临指教。

Notice to Microsoft Windows® 2000 Users

- After a successful software installation, you are required to reboot your computer. The Windows® 2000 Hardware Manager will then try to detect your newly installed hardware. You may be asked if you would like to continue the installation. Please click "Yes" to continue.
- Microsoft's digital signature is issued to Windows® -compatible products. Our driver is so new. It is still undergoing tests by Microsoft.
- Please check our web site for latest update.

? 关于在线辅助帮助

- 您有许多方式可以取得疑难排出以及产品的使用信息。
- 1. 在Windows®的开始菜单中选择程序然后选择扫描仪。
- 2. 在窗口右下角的直接扫描图标菜单中选择扫描仪帮助。
- 3. 选择软件面板上的辅助帮助键。

? Help on Procedures

- There are various ways of obtaining trouble-shooting and customer care information.
- 1. Click Start on your Windows® taskbar, then click Programs to select your scanner model. Click Help System.
- 2. Select Scanner Help on the Direct Scan icon of your Windows® taskbar.
- 3. Click the Help button found in the Panel.

产品规格

扫描仪机种	彩色 CCD 平台
扫描范围	8.5" x 11.7" (216 mm x 297 mm)
最大	
扫描模式	全彩
True 48-bit	
灰阶	True 16-bit
文字/线稿	1 bit/pixel (2 levels)
解析度	1200dpi (H) x 2400dpi (V)
接口	快速 USB2.0
操作系统支持	Windows® 98se/Me/2000/XP/Vista
耗电率	15W (12V,1.25A)
开关电源变压器	
扫描仪尺寸	436 x 261 x 80 mm (L x W x H)
扫描仪重量	2.4 Kg (5.3 lbs)